

	A	B	C	D	E	F	G	H	I	J	K	L	M	N
1	Brand	Model	Version	CPU	Cores	Mhz	Flash	RAM	Eth 1G	Install	Upgrade	OEM	Wiki	Device Type
2	APRESIA	ApresiaLightGS120GT-SS (APLGS120GTSS)		Realtek RTL8382M	1	500	["32"]	256	20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://www.apresia.jp/products/apresialight/aplgs120gtss.html"]	["http://"]	Switch
3	D-Link	DGS-1210-20	["F1"]	Realtek RTL8382M	1	500	["32"]	128	20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["http://"]	["http://"]	Switch
4	D-Link	DGS-1210-26	["F1"]	Realtek RTL8382M	1	500	["32"]	128	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://www.dlink.com/en/product"]	["https://wikidevi.wi-cat.ru/D-Link"]	Switch
5	D-Link	DGS-1210-28	["F1", "F2", "or newer (old)"]	Realtek RTL8382M	1	500	["32"]	128	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://eu.dlink.com/uk/en/product"]	["https://wikidevi.wi-cat.ru/D-Link"]	Switch
6	D-Link	DGS-1210-28MP	["F1", "F2", "or newer (old)"]	Realtek RTL8382M	1	500	["32"]	128	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/targets/realtek"]	["https://wikidevi.wi-cat.ru/D-Link"]	Switch
7	D-Link	DGS-1210-28P	["F1", "F2 or newer (old)"]	Realtek RTL8382M	1	500	["32"]	128	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://www.dlink.com/us/en/product"]	["https://wikidevi.wi-cat.ru/D-Link"]	Switch
8	D-Link	DGS-1210-52	["F1", "F2 or newer (old)"]	Realtek RTL8393M	1	700	["32"]	128	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://www.dlink.com/us/en/product"]	["https://wikidevi.wi-cat.ru/D-Link"]	Switch
9	HPE	1920-24G (JG924A)		Realtek RTL8382M	1	500	["32"]	128	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://www.hpe.com/psnow/doc/"]	["https://wikidevi.wi-cat.ru/Hewlett-Packard"]	Switch
10	HPE	1920-24G-PoE+ (180W) (JG925A)		Realtek RTL8382M	1	500	["32"]	128	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/targets/realtek/rtl838x/openwrt-24.10.0-realte"]	["https://wikidevi.wi-cat.ru/Hewlett-Packard"]	Switch
11	HPE	1920-24G-PoE+ (370W) (JG926A)		Realtek RTL8382M	1	500	["32"]	128	more than 20	["https://downloads.openwrt.org/releases/24.10.2/tar"]	["https://downloads.openwrt.org/releases/24.10.2/tar"]	["https://downloads.openwrt.org/releases/24.10.2/targets/realtek/rtl838x/openwrt-24.10.2-realte"]	["https://wikidevi.wi-cat.ru/Hewlett-Packard"]	Switch
12	HPE	1920-48G (JG927A)	["HNG7A-HA0015"]	Realtek RTL8393M	1	650	["32"]	128	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/targets/realte"]	["https://wikidevi.wi-cat.ru/Hewlett-Packard"]	Switch
13	HPE	1920-48G-PoE+ (370W) (JG9: ["HNGZA-HA0016"])		Realtek RTL8393M	1	650	["32"]	128	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/targets/realte"]	["https://wikidevi.wi-cat.ru/Hewlett-Packard"]	Switch
14	I-O Data	B5H-G24MB		Realtek RTL8382M	1	500	["16"]	128	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://www.iodata.jp/lib/product/b/6306.htm"]	["https://wikidevi.wi-cat.ru/I-O-Data"]	Switch
15	NETGEAR	GS750E		Realtek RTL8393M	1	700	["8"]	128	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://www.netgear.com/business/wired/switches/plus/gs750e/"]	["https://wikidevi.wi-cat.ru/Netgear"]	Switch
16	Panasonic	Switch-M24eG PN28240K		Realtek RTL8382M	1	500	["32"]	128	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://panasonic.co.jp/ew/pewnw/"]	["https://wikidevi.wi-cat.ru/Panasonic"]	Switch
17	Panasonic	Switch-M48eG PN28480K		Realtek RTL8393M	1	700	["32"]	128	more than 20	["https://downloads.openwrt.org/releases/24.10.2/tar"]	["https://downloads.openwrt.org/releases/24.10.2/tar"]	["https://panasonic.co.jp/ew/pewnw/product/lan/m48eg_new.html"]	["https://wikidevi.wi-cat.ru/Panasonic"]	Switch
18	TP-Link	T1600G-28TS	["v3"]	Realtek RTL8382M	1	500	["32"]	256	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://www.tp-link.com/us/business-networking/smart-switch/t1600g-28ts"]	["https://wikidevi.wi-cat.ru/TP-Link"]	Switch
19	TP-Link	T1600G-52PS	["v4"]	Realtek RTL8393M	1	500	["32"]	256	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://www.tp-link.com/us/business-networking/smart-switch/t1600g-52ps"]	["https://wikidevi.wi-cat.ru/TP-Link"]	Switch
20	TP-Link	TL-SG2452P	["v4"]	Realtek RTL8393M	1	500	["32"]	256	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://www.tp-link.com/ae/business-networking/smart-switch/tl-sg2452p"]	["https://wikidevi.wi-cat.ru/TP-Link"]	Switch
21	ZyXEL	GS1900-24	["v1"]	Realtek RTL8382M	1	500	["16"]	64	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://www.zyxel.com/us/en/product"]	["https://wikidevi.wi-cat.ru/ZyXEL"]	Switch
22	ZyXEL	GS1900-24E		Realtek RTL8382M	1	500	["16"]	128	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["http://www.zyxel.com/us/en/product"]	["https://wikidevi.wi-cat.ru/ZyXEL"]	Switch
23	ZyXEL	GS1900-24EP		Realtek RTL8382M	1	500	["16"]	128	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["http://www.zyxel.com/us/en/product"]	["https://wikidevi.wi-cat.ru/ZyXEL"]	Switch
24	ZyXEL	GS1900-24HP	["v2"]	Realtek RTL8382M	1	500	["16"]	128	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://www.zyxel.com/us/en/product"]	["https://wikidevi.wi-cat.ru/ZyXEL"]	Switch
25	ZyXEL	GS1900-24HP	["v1"]	Realtek RTL8382M	1	500	["16"]	64	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://www.zyxel.com/de/de/product"]	["https://wikidevi.wi-cat.ru/ZyXEL"]	Switch
26	ZyXEL	GS1900-48		Realtek RTL8393M	1	700	["16"]	128	more than 20	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://downloads.openwrt.org/releases/24.10.0/tar"]	["https://www.zyxel.com/us/en/product"]	["https://wikidevi.wi-cat.ru/ZyXEL"]	Switch